

October 25, 2010

**Frigidaire and Electrolux ICON Electric Smoothtop Cooktops and Slide-In Ranges Recalled Due to Fire Hazard**

**Toronto, ON** – The Electrical Safety Authority is notifying the public that the Frigidaire Division of Electrolux Home Products, Inc. (“**Frigidaire**”) has announced a voluntary recall (the “**Recall**”) of the following consumer products. Consumers should unplug and stop using recalled products immediately.

**Name of Products:** Frigidaire® and Electrolux ICON® Electric Smoothtop Cooktops and Slide-in Ranges with rotary knobs and digital displays, as described in the chart below.

**Number of Units:** Approximately 28,000

**Manufacturer:** Frigidaire

**Canadian Distributor:** Electrolux Canada Corp.

**Hazard:** Liquids can pool under the control knobs and cause a surface heating element to turn on unexpectedly, heat to temperatures other than expected and then not turn off, posing a risk of fire and burn hazards to consumers.

**Incidents/Injuries:** The company is not aware of any reports of serious injuries or substantial property damage in Canada related to these issues.

**Description/Models:** This recall involves Frigidaire and Electrolux ICON Electric Smoothtop Cooktops and Frigidaire Slide-in Ranges with rotary knobs and digital displays. Model and serial numbers for the slide-in ranges can be found inside the oven door on the left side of the unit or on the underside of cooktop models. The following model and serial numbers are included in this recall (the “**Affected Units**”):

FRIGIDAIRE SLIDE-IN UNITS	
MODEL NUMBERS BEGINNING WITH THESE LETTERS AND NUMBERS	SERIAL NUMBER RANGE
CGLES389EB	NF501xxxxx-NF652xxxxx
CGLES389ES	NF501xxxxx-NF652xxxxx
CGLES389FB	NF601xxxxx-NF852xxxxx
CGLES389FS	NF601xxxxx-NF952xxxxx
CPLES399EC	NF501xxxxx-NF952xxxxx
GLES389EB	NF501xxxxx-NF652xxxxx
GLES389EQ	NF501xxxxx-NF652xxxxx
GLES389ES	NF501xxxxx-NF652xxxxx
GLES389FB	NF601xxxxx-NF952xxxxx
GLES389FQ	NF601xxxxx-NF752xxxxx
GLES389FS	NF601xxxxx-NF952xxxxx
LES389FE	NF601xxxxx-NF652xxxxx
PLES389EC	NF501xxxxx-NF952xxxxx
PLES399EC	NF501xxxxx-NF952xxxxx

FRIGIDAIRE COOKTOP UNITS	
MODEL NUMBERS BEGINNING WITH THESE LETTERS AND NUMBERS	SERIAL NUMBER RANGE
GLEC30S9EB	NF501xxxxx-NF752xxxxx
GLEC30S9EQ	NF601xxxxx-NF752xxxxx
GLEC30S9ES	NF501xxxxx-NF652xxxxx
GLEC36S9EB	NF501xxxxx-NF752xxxxx
GLEC36S9EQ	NF501xxxxx-NF652xxxxx
GLEC36S9ES	NF501xxxxx-NF752xxxxx
LEEC30S9FE	NF601xxxxx-NF652xxxxx
LEEC36S9FE	NF601xxxxx-NF652xxxxx
PLEC30S9EC	NF501xxxxx-NF952xxxxx

October 25, 2010

PLEC36S9EC	NF501xxxxx-NF952xxxxx
<b>ELECTROLUX ICON COOKTOP UNITS</b>	
<b>MODEL NUMBERS BEGINNING WITH THESE LETTERS AND NUMBERS</b>	<b>SERIAL NUMBER RANGE</b>
E30EC65ESS	NF501xxxxx-NF045xxxxx
E36EC65ESS	NF501xxxxx-NF045xxxxx

**Sold by:** Retailers across Canada.

**Dates distributed:** The Affected Units were sold in Canada from approximately January 2005 to August 2010.

**Manufactured in:** Canada

**Remedy:** Consumers should immediately stop using Affected Units, unplug the recalled ranges from the electrical outlet or power off the cooktops at the circuit breaker. Contact the company for information on how to obtain a free repair kit.

**Consumer Contact:** Consumers should call 1-800-777-9241 toll free between the hours of 8:00 a.m. and 10:00 p.m. Eastern Time, Monday to Saturday, or go to the following websites: [www.cooktoprecall.ca](http://www.cooktoprecall.ca) or [www.rappeltablesdecuisson.ca](http://www.rappeltablesdecuisson.ca) (for Electrolux ICON Models) or [www.smoothtoprangerecall.ca](http://www.smoothtoprangerecall.ca) or [www.rappelcuisinieresurfacelisse.ca](http://www.rappelcuisinieresurfacelisse.ca) (for Frigidaire Models).

**Remarks:** The Affected Units are certified to Canadian standards by the CSA. For more information about the product certification process please visit: [www.csa.ca](http://www.csa.ca)



October 25, 2010

Sample smoothtop slide-in range with rotary knobs and digital displays



Sample Smoothtop cooktop with rotary knobs and digital displays



Slide-in serial plate – left side of oven with door open



Cooktop serial plate – underside of unit