

June 29, 2012

Robert Bosch Tool Corporation Recalls Skil® Circular Saws Due to Laceration Hazard

The Electrical Safety Authority is notifying the public that Robert Bosch Tool Corporation has announced a voluntary recall of the following consumer product. Consumers should stop using recalled products immediately.

Name of Product: Skil® Brand Circular Saws

Units: 618 units sold in Canada

Manufacturer/Importer: Robert Bosch Tool Corporation

Hazard: The lower guard hub can break allowing the lower guard to contact the blade during use.

Incidents/Injuries: No injuries or damage reported.

Description/Models: Skil® Model 3316 Miter Saw with only the following date codes: 111, 112, 201,202, 203, 204 with suggested retail price of CAD \$119. Note: Some miter saws were bundled with a Skil® model 3310 table saw and the table saw is not affected by this recall.

Sold by: Various retailers nationwide including Canadian Tire, The Home Depot and Rona.

When was distributed: January 2012 to April 2012.

Manufactured in: China

Remedy: Consumers should immediately stop using the miter saw and contact Robert Bosch Tool Corporation for a lower guard replacement kit.

Consumer Contact: Contact Bosch Tool Corporation at 1-888-727-6109 between 7 a.m. and 7 p.m. Monday to Friday, or visit the firm’s website at www.skiltools.com.

Remarks: The recalled units are certified to Canadian Standards by Underwriters Laboratories Inc. (UL). For more information about Underwriters Laboratories product certification process please visit: www.UL.com.

SKILSAW® Model 3316 Compound Miter Saw

Models 3316-01 and 3316-02 Manufactured with Date Code:

111	112	201	202	203	204
-----	-----	-----	-----	-----	-----

June 29, 2012



WARNING To reduce risk of injury, user must read and understand the instruction manual. ▲ Wear eye and respiratory protection. ▲ Use saw blade rated 5000/min or greater. ▲ Do not use saw without functioning guard system. If guard doesn't operate smoothly, have it serviced. After changing blade return guard to operating position. ▲ Keep hands a safe distance from saw blade. Always keep outside of No-Hands zone. ▲ Disconnect saw from power source before servicing or changing blade. ▲ Never reach around or in the back of the saw blade. ▲ Hold or clamp workpiece against base and fence. Never perform any operation freehand. ▲ Do not Cross-Hand cut. Never place your hands or arms across the projected saw blade path. With motor OFF, make a Dry-Run to be aware of the blade's reach. ▲ After turning saw OFF, keep saw in the down position and wait for blade to stop before removing cutoff pieces or changing settings. ▲ To avoid electrical shock, do not expose to rain or use in damp locations. ▲ When servicing use only identical replacement parts. ▲ Always use auxiliary stand to support long workpieces. ▲ Always use the clamp to support the workpiece when making a compound miter cut. Do not support by hand.

SKILSAW® 3316

Ø10"(254mm) COMPOUND MITER SAW
120V - 60Hz 15A n_c 5000/min (RPM) cUL US
F012331600 LISTED 1000, 2500 111
Rubber Bosch Tool Corp. MOUNT PROSPECT, IL, Made in China 1102254

Date Code